



Next Generation Pill Counting • Built-in Digitized/Remote Final Check

Verify Every Pill Safely & Securely From Anywhere*

Networked for Success



Patient Safety
Optimized



PV2 Remote
Final Check



Inventory
Management



PMS
Integration



Secure
Connectivity

Features

- Counts & verifies all oral solid medication including clear gel caps.
- For each vial-filled script or pre-pack, captures clear, accurate images of every pill on the counting tray, label on the vial, and pills in the vial. **All with pill verification.**
- Pill properties are combined with patient information, lot number and expiration date and recorded in the database along with date, time and biometric operator identity.
- Data is transferred over a secure network to other pharmacists, enabling them to perform digitized remote final check functions, in pharmacy or remotely.
- Upon pharmacist approval, the prescription is released from will-call by the clerk to the patient.
- Built-in pill verification alerts the fill tech of an error requiring correction before the script can be filled and is presented to the pharmacist for final check function.
- Added security for tech check tech.

*With Secure Network



2453 Cades Way, Bldg A • Vista, CA 92081 | 877-797-2332 | info@rxsafe.com

VisionRx™ Easy To Use • Safe & Accurate

Specifications for VisionRx

Dimensions	W=14" L=11.75" H=23.3" W=35.56 cm L=29.85 cm H=59.18 cm
Weight	31.7 lbs 14.38 kg
Platter Surface	9.7" W x 8.1" L 24.64 cm x 20.57 cm
Barcode Scanner	Linear and 2D barcodes, biometric fingerprint scanner-enabled.
Communications	Use your secure pharmacy network to communicate to pharmacy management software.
Internal Temperature/Humidity	Same as pharmacy space.
Cleaning	Quickly wipe down with alcohol wipe.
NDC Validation	All medications (tablets/1/2 tablets/capsules/soft gels/clear gels and unit-of-use) can be validated by scanning the barcode on the pharmacy label & then the barcode on the medication stock bottle/box. Recognizes generic equivalent, and allows for substitution.
Bi-Directional Interfacing	Interface bi-directionality enabled.
Counting Technology	Vision verification counting system. Counts & verifies all medications including clear gels.
Pill Verification	Full pill verification utilizing size, shape & color features based on scanned NDC number.
Annotated Tray Photo	Color photo of pill tray with Rx Number, Refill, tray count, tray number, quantity needed, counted by, counted on date/time, NDC, barcode, expiration date, lot number, container serial number (if applicable), product description (product name, strength & dosage form).

Specifications for RxSafe Controller (built-in)

Processor Intel® Core™ i7	Storage 512GB RAM 16GB
Operating System Microsoft Windows 10 PRO	Power 110 volt A/C, 60 Hz, 5 amp

Features & Benefits

- 99.99% Accurate counting and verification
- Recognizes and prevents broken pills/debris
- Pour as fast as you can, counts 5x per second (every 200ms)
- Full pill verification utilizing size, shape & color features based on scanned NDC number
- USP <800> compliant with multiple cleanable, reusable trays
- User ID and password or biometric sign-in required. All activities tracked.
- Large 10.1" Touchscreen Display
- Automatic, configurable tray shaker for faster counts
- Digital Final Check (PV2): Photos of tray(s), pills in vial (top view), vial label & stock bottle label. API provides photos to PMS.

Custom Pharmacy Layout Services

Workflow Optimization Integrates VisionRx automation into existing pharmacy systems



2453 Cades Way, Bldg A • Vista, CA 92081 | 877-797-2332 | info@rxsafe.com